Digitrax Decoder Specification Sheet

DN135D 1 Amp N/HO Scale Mobile Decoder



Physical	.55" x .406" x .2"	Current Rating	1.0/1.25 Amps
Size	13.97mm x 10.312mm x 5.08mm		

Interface	Decoder End	Wires		Locomotive End/Plug
N Harness	Digitrax N Scale Harness	4.5"	114 mm	Wires

# Functions	3	Function	500mA	Function	FX^3
		Current Rating		Type	
Prod Date	06-15-	Discontinued	Current	Replaced By	Current
	2010				
MSRP	US\$18.95	Feature Set	Series 5		

FX³ **decoders** have motor isolation protection. If the decoder senses that the motor is not isolated, it will not run the motor. In this case, you will be able to control the loco's functions but the motor will not work.

Series 5 decoders have all Series 3 Features plus are able to host a sound bug sound only decoder.

CVs are used for this decoder

CV#	Feature	Default	Range	Notes
Locor	notive Address CVs			
01	2 Digit Decoder Address	03	001-127	
17	4 Digit Address (High Byte)	00	0128-9983	CV17 & 18 are used
18	4 Digit Address (Low Byte)	00	0128-9983	Together to program the 4 digit address. Current production Digitrax throttles handle this automatically. See calculator below if separate values are needed by your system for programming 4 digit address

	T -: -: -	1 _	T -:	T = -
29	Configuration Register	06	See CV29	Must be set to a value
	Controls Multiple Features		Value Table	that allows either 2 digit
			Below	or 4 digit addressing
Conf	iguration Register CV			
29	Configuration Register	06		
	Address Selection, 2 or 4 digit	2 Digit	2 or 4 Digit	
	Normal Direction of Travel	Fwd	Fwd/Rev	
	(NDOT)			
	Speed Step Control	28/128	14 or 28/128	
	Speed Table On/Off	Off	Speed Table	
			On or Off	
	Analog Mode Conversion	On	On or Off	
	On/Off			
Loco	motion CVs-Control			
Loco	motive Motion			
Char	acteristics			
Acce	leration and Deceleration			
03	Acceleration Rate	00	00 to 31	128 Steps
04	Deceleration Rate	00	00 to 31	128 Steps
Thre	e Step Simple Speed Table & St	art Volta	ge	-
02	Start Voltage	00	00 to 255	128 Steps
05	Maximum Voltage	00	00 to 255	128 Steps
				00, 01 & 255 = max
				voltage at step 28
06	Mid Point Voltage	00	00 to 255	128 Steps
				00 & 01= straight line
				curve
28 St	ep Speed Tables with 256 Step 1	Resolution	1	
65	Kick Start value	00		128 Step Interpolated
66	Forward Trim	00		128 Step Interpolated
67	First Speed Table Entry	00		128 Step Interpolated
68-	28 Step Speed Table Entries	00		128 Step Interpolated
93				
94	Maximum Speed Table Step	00		128 Step Interpolated
95	Reverse Trim	00		128 Step Interpolated
29	Configuration Register	06	See Above	Must be set to a value
_,		Speed	CV29	that enables speed tables
		Tables		r
		are		
		disable		
		d		
_	ue Compensation and	1		
53	ching Speed FX ³ Decoders do not use	NA	N A	Not Available
FX^3		INA	NA	NOT Available
	CV53			Can imptymentian almost C
53	FX Decoders used CV53 to			See instruction sheet for
FX	designate FX effect generated			the FX decoder you are
5.1	on F3-Brown Wire	00	00 00 00 70	using
54	FX ³ Decoders use CV54 to	00	00=SS Off, TC	

FX ³	control		On	
	Switching Speed &		01=SS On, TC	
	Torque Compensation		On	
			16=SS Off, TC	
			Off	
			17=SS On, TC	
			Off	
53	FX Decoders used CV54 to			See instruction sheet for
FX	designate FX effect generated			the FX decoder you are
	on F4-White/Yellow Wire			using
Funct			_	2
13	DC Functions ON Not Used in FX ³		Automatic	Not Used FX ³
FX^3F	unctions			
49	F0F, forward light effect	00	See FX ³	
	white	<u> </u>	section	
50	F0R, reverse light effect	00	See FX ³	
	yellow		section	
51	F1, Function 1 green	00	See FX ³	
			section	
52	F2, Function 2 violet	00	See FX ³	
			section	
113	F3, Function 3 brown	00		Not Available
114	F4, function 4 white/yellow	00		Not Available
115	F5, Function F5 white/green	00		Not Available
116	F6, Function F6 white/blue	00		Not Available
62	FX Rate and Keep alive adjust	00	00 to 255	
63	Ditch Light Blink hold time	00	00 to 255	
	Master Light Switch			See FX ³ section
Direc	tional Headlights, Transpondin	g, Split F	ield Motor	
61	Directional Headlight	1	Map F0	Not controlled by CV61
	_	onal	Forward &	in FX ³ Decoders
			Reverse	
			See CV61	
			Section	
	Transponding	Off	Off or On	
			See CV61	
		_	Section	
	Split Field Motor	Off	Off or On	For AC Motors
			See CV61 Section	
Scale	able Speed Stabilization (Back)	EMF)	Section	
55	Static Compensation	128	00 to 255	
56	Dynamic Compensation	048	00 to 255	
57	Speed Stabilizer-Droop	006	00 to 15	
	rSonic (Quiet Operation)	1		
09	Motor Frequency SuperSonic	00	00 to 255	Default is MAX
	nced Consisting			
	ð			

19	Advanced Consist Address	00	00 to 255	Default is OFF
21	Advanced Consist Function	00	See CV21-22	
	Control Override for F1-F8		Section	
22	Advanced Consist Function	00	See CV21-22	
	Control Override for F0 &		Section	
	F9-F12			
Funct	ion Mapping			
33-	Function Mapping CVs	00	See Function	
46			Mapping	
			Section	
Decod	ler Reset to Default Values			
00	Reset Decoder to Factory	129	Set to 08 to	Set to 09 to reset all CV
08	Reset Decoder to 1 actory	12)	500 00 00	
08	Default CV Values	12)	reset all CV	Values except 28 step
08	,			Values except 28 step speed table.
	,	12)	reset all CV	1 1
	Default CV Values	00	reset all CV	1 1
Decod	Default CV Values ler IDs		reset all CV	speed table.
Decod 105	Default CV Values ler IDs User Private ID #1	00	reset all CV	speed table. User Defined
Decod 105 106	Default CV Values ler IDs User Private ID #1 User Private ID #2	00 00	reset all CV Values.	speed table. User Defined User Defined

Information provided here is correct to the best of our knowledge.