## **Digitrax Decoder Specification Sheet**

## DG383AR 3 Amp Mobile Decoder with AristoCraft Plug



Physical	1.45" x 2.23"	<b>Current Rating</b>	3.0/5.0 Amps
Size	36.83mm x 56.64mm		

Interface	Decoder End	Wires		Locomotive End/Plug
Aristocraft Plug	Aristocraft Plug	N/A	N/A	Aristocraft Socket

<b># Functions</b>	8	Function	2 Amps	Function	FX <sup>3</sup>
		<b>Current Rating</b>		Туре	
Prod Date	07/30/2002	Discontinued	Current	<b>Replaced By</b>	Current
MSRP	US\$59.99	Feature Set	Series 3		

 $FX^3$  decoders have motor isolation protection. If the decoder senses that the motor is not isolated, it will not run the motor. In this case, you will be able to control the loco's functions but the motor will not work.

## CVs are used for this decoder

CV#	Feature	Default	Range	Notes
Loco	notive Address CVs			
01	2 Digit Decoder Address	03	001-127	
17	4 Digit Address (High Byte)	00	0128-9983	CV17 & 18 are used
18	4 Digit Address (Low Byte)	00	0128-9983	Together to program the 4 digit address. Current production Digitrax throttles handle this automatically. See calculator below if separate values are needed by your system for programming 4 digit address

29	Configuration Register	06	See CV29	Must be set to a value
2)	Controls Multiple Features	00	Value Table	that allows either 2 digit
	Controls Multiple readiles		Below	or 4 digit addressing
Conf	iguration Register CV		DCIOW	
29	Configuration Register	06		
2)	Address Selection, 2 or 4 digit	2 Digit	2 or 4 Digit	
	Normal Direction of Travel	Fwd	Fwd/Rev	
	(NDOT)			
	Speed Step Control	28/128	14 or 28/128	
	Speed Table On/Off	Off	Speed Table On or Off	
	Analog Mode Conversion On/Off	On	On or Off	
Loco	motion CVs-Control			
	motive Motion			
	cacteristics			
	leration and Deceleration			
03	Acceleration Rate	00	00 to 31	128 Steps
04	Deceleration Rate	00	00 to 31	128 Steps
	e Step Simple Speed Table & St			
02	Start Voltage	00	00 to 255	128 Steps
05	Maximum Voltage	00	00 to 255	128 Steps
00	in a straige	00	00 10 200	$00, 01 \& 255 = \max$
				voltage at step 28
06	Mid Point Voltage	00	00 to 255	128 Steps
00	inter i onne i onnege	00	0010200	00 & 01 = straight line
				curve
28 St	ep Speed Tables with 256 Step 1	Resolution	1	
65	Kick Start value	00		128 Step Interpolated
66	Forward Trim	00		128 Step Interpolated
67	First Speed Table Entry	00		128 Step Interpolated
68- 93	28 Step Speed Table Entries	00		128 Step Interpolated
94	Maximum Speed Table Step	00		128 Step Interpolated
95	Reverse Trim	00		128 Step Interpolated
29	Configuration Register	06	See Above	Must be set to a value
		Speed Tables are disable d	CV29	that enables speed tables
-	ue Compensation and ching Speed			
53	$FX^3$ Decoders do not use	NA	NA	Not Available
$FX^3$	CV53			
53	FX Decoders used CV53 to			See instruction sheet for
FX	designate FX effect generated			the FX decoder you are
	on F3-Brown Wire			using
54	FX <sup>3</sup> Decoders use CV54 to	00	00=SS Off, TC	

FX <sup>3</sup>	control		On	
ľΛ	Switching Speed &		01=SS On, TC	
	Torque Compensation		On On	
	Torque Compensation		16=SS Off, TC	
			Off	
			17=SS On, TC	
			Off	
53	FX Decoders used CV54 to			See instruction sheet for
FX	designate FX effect generated			the FX decoder you are
	on F4-White/Yellow Wire			using
Funct	tions			
13	DC Functions ON Not Used		Automatic	Not Used FX <sup>3</sup>
	in FX <sup>3</sup>			
FX <sup>3</sup> F	Functions			
49	F0F, forward light effect	00	See FX <sup>3</sup>	
	white		section	
50	F0R, reverse light effect	00	See FX <sup>3</sup>	
	yellow		section	
51	F1, Function 1 green	00	See FX <sup>3</sup>	
			section	
52	F2, Function 2 violet	00	See FX <sup>3</sup>	
			section	
113	F3, Function 3 brown	00		Not Available
114	F4, function 4 white/yellow	00		Not Available
115	F5, Function F5 white/green	00		Not Available
116	F6, Function F6 white/blue	00		Not Available
62	FX Rate and Keep alive	00	00 to 255	
63	adjust Ditch Light Blink hold time	00	00 to 255	
05	Master Light Switch	00	0010233	See FX <sup>3</sup> section
Direc	tional Headlights, Transpondir	l 19 Snlit F	ield Motor	See PA see 101
61	Directional Headlight	Directi	Map F0	Not controlled by CV61
01	Directional freadingin	onal	Forward &	in FX <sup>3</sup> Decoders
		onui	Reverse	
			See CV61	
			Section	
	Transponding	Off	Off or On	
			See CV61	
			Section	
	Split Field Motor	Off	Off or On	For AC Motors
			See CV61	
a -			Section	
	able Speed Stabilization (Back		00 / 055	
55	Static Compensation	128	00 to 255	
56	Dynamic Compensation	048	00 to 255	
57	Speed Stabilizer-Droop	006	00 to 15	
	rSonic (Quiet Operation)	00	00.4- 055	Defeelt : MAX
09	Motor Frequency SuperSonic	00	00 to 255	Default is MAX
Adva	nced Consisting			

19	Advanced Consist Address	00	00 to 255	Default is OFF
21	Advanced Consist Function	00	See CV21-22	
	Control Override for F1-F8		Section	
22	Advanced Consist Function	00	See CV21-22	
	Control Override for F0 &		Section	
	F9-F12			
Funct	tion Mapping			
33-	Function Mapping CVs	00	See Function	
46			Mapping	
			Section	
Deco	ler Reset to Default Values			
08	Reset Decoder to Factory	129	Set to 08 to	Set to 09 to reset all CV
	Default CV Values		reset all CV	Values except 28 step
			Values.	speed table.
Deco	ler IDs			
105	User Private ID #1	00		User Defined
106	User Private ID #2	00		User Defined
07	Version ID	64	Digitrax	Read Only
			Version ID	-
08	Manufacturer ID	129	Digitrax	Not affected by reset

Information provided here is correct to the best of our knowledge.