

# Digitrax Decoder Specification Sheet

---

## DH126PS 1.5 Amp Economy HO Scale Decoder with Digitrax Easy Connect 9 Pin to DCC Medium Plug 1.0” Harness



|                      |   |                       |               |
|----------------------|---|-----------------------|---------------|
| <b>Physical Size</b> | 0.672” x 1.074” x 0.259”<br>17.08mm x 27.28mm x 6.6mm | <b>Current Rating</b> | 1.25/2.0 Amps |
|----------------------|---|-----------------------|---------------|

| Interface | Decoder End    | Wires |         | Locomotive End/Plug |
|-----------|----------------|-------|---------|---------------------|
| DH126D    | Digitrax 9 Pin | 7.0”  | 177.8mm | DCC Med             |
| DH126PS   | Digitrax 9 Pin | 1.0”  | 25.4 mm | DCC Med             |

| PowerXtender Interface | Decoder End    |
|------------------------|----------------|
| PX112-2                | Digitrax 2 Pin |

|                    |            |                                |          |                      |                 |
|--------------------|------------|--------------------------------|----------|----------------------|-----------------|
| <b># Functions</b> | 2          | <b>Function Current Rating</b> | 500mA    | <b>Function Type</b> | FX <sup>3</sup> |
| <b>Prod Date</b>   | 02/04/2014 | <b>Discontinued</b>            | Current  | <b>Replaced By</b>   | Current         |
| <b>MSRP</b>        | US\$23.00  | <b>Feature Set</b>             | Series 6 | <b>SKU</b>           |                 |

**FX<sup>3</sup> decoders** have motor isolation protection. If the decoder senses that the motor is not isolated, it will not run the motor. In this case, you will be able to control the loco’s functions but the motor will not work.

**CVs are used for this decoder**

| CV#   | Feature   | Default | Range                      | Notes  |
|---|---|---------|----------------------------|--|
| <b>Locomotive Address CVs</b>                                   |   |         |                            |  |
| 01  | 2 Digit Decoder Address                           | 03      | 001-127                    |  |
| 17  | 4 Digit Address (High Byte)                       | 00      | 0128-9983                  | CV17 & 18 are used Together to program the 4 digit address. Current production Digitrax throttles handle this automatically. See calculator below if separate values are needed by your system for programming 4 digit address |
| 18  | 4 Digit Address (Low Byte)                        | 00      | 0128-9983                  |  |
| 29  | Configuration Register Controls Multiple Features | 06      | See CV29 Value Table Below | Must be set to a value that allows either 2 digit or 4 digit addressing  |
| <b>Configuration Register CV</b>                                |   |         |                            |  |
| 29  | Configuration Register                            | 06      |                            |  |
|   | Address Selection, 2 or 4 digit                   | 2 Digit | 2 or 4 Digit               |  |
|   | Normal Direction of Travel (NDOT)                 | Fwd     | Fwd/Rev                    |  |
|   | Speed Step Control                                | 28/128  | 14 or 28/128               |  |
|   | Speed Table On/Off                                | Off     | Speed Table On or Off      |  |
|   | Analog Mode Conversion On/Off                     | On      | On or Off                  |  |
| <b>Locomotion CVs-Control Locomotive Motion Characteristics</b> |   |         |                            |  |
| <b>Acceleration and Deceleration</b>                            |   |         |                            |  |
| 03  | Acceleration Rate                                 | 00      | 00 to 31                   | 128 Steps  |
| 04  | Deceleration Rate                                 | 00      | 00 to 31                   | 128 Steps  |
| <b>Three Step Simple Speed Table &amp; Start Voltage</b>        |   |         |                            |  |
| 02  | Start Voltage                                     | 00      | 00 to 255                  | 128 Steps  |
| 05  | Maximum Voltage                                   | 00      | 00 to 255                  | 128 Steps<br>00, 01 & 255= max voltage at step 28  |
| 06  | Mid Point Voltage                                 | 00      | 00 to 255                  | 128 Steps<br>00 & 01= straight line curve  |
| <b>28 Step Speed Tables with 256 Step Resolution</b>            |   |         |                            |  |
| 65  | Kick Start value                                  | 00      |                            | 128 Step Interpolated  |
| 66  | Forward Trim                                      | 00      |                            | 128 Step Interpolated  |

|  |  |  |  |  |
|--|--|--|--|--|
| 67   | First Speed Table Entry  | 00   |  | 128 Step Interpolated                                  |
| 68-93  | 28 Step Speed Table Entries  | 00   |  | 128 Step Interpolated                                  |
| 94   | Maximum Speed Table Step   | 00   |  | 128 Step Interpolated                                  |
| 95   | Reverse Trim   | 00   |  | 128 Step Interpolated                                  |
| 29   | Configuration Register   | 06<br>Speed<br>Tables<br>are<br>disable<br>d | See Above<br>CV29  | Must be set to a value<br>that enables speed tables    |
| <b>Torque Compensation and Switching Speed</b> |  |  |  |  |
| 53<br>FX <sup>3</sup>                          | FX <sup>3</sup> Decoders do not use CV53   | NA   | NA   | Not Available  |
| 53<br>FX                                       | FX Decoders used CV53 to designate FX effect generated on F3-Brown Wire            |  |  | See instruction sheet for the FX decoder you are using |
| 54<br>FX <sup>3</sup>                          | FX <sup>3</sup> Decoders use CV54 to control Switching Speed & Torque Compensation | 00   | 00=SS Off, TC On<br>01=SS On, TC On<br>16=SS Off, TC Off<br>17=SS On, TC Off |  |
| 53<br>FX                                       | FX Decoders used CV54 to designate FX effect generated on F4-White/Yellow Wire     |  |  | See instruction sheet for the FX decoder you are using |
| <b>Functions</b>                               |  |  |  |  |
| 13   | DC Functions ON Not Used in FX <sup>3</sup>  |  | Automatic  | Not Used FX <sup>3</sup>                               |
| <b>FX<sup>3</sup> Functions</b>                |  |  |  |  |
| 49   | F0F, forward light effect white  | 00   | See FX <sup>3</sup> section  |  |
| 50   | F0R, reverse light effect yellow   | 00   | See FX <sup>3</sup> section  |  |
| 51   | F1, Function 1 green   | 00   | See FX <sup>3</sup> section  |  |
| 52   | F2, Function 2 violet  | 00   | See FX <sup>3</sup> section  |  |
| 113  | F3, Function 3 brown   | 00   |  | Not Available  |
| 114  | F4, function 4 white/yellow  | 00   |  | Not Available  |
| 115  | F5, Function F5 white/green  | 00   |  | Not Available  |
| 116  | F6, Function F6 white/blue   | 00   |  | Not Available  |
| 62   | FX Rate and Keep alive adjust  | 00   | 00 to 255  |  |
| 63   | Ditch Light Blink hold time  | 00   | 00 to 255  |  |
|  | Master Light Switch  |  |  | See FX <sup>3</sup> section                            |

| <b>Directional Headlights, Transponding, Split Field Motor</b> |  |             |  |  |
|--|--|-------------|--|--|
| 61   | Directional Headlight                                      | Directional | Map F0 Forward & Reverse<br>See CV61 Section | Not controlled by CV61 in FX <sup>3</sup> Decoders           |
|  | Transponding   | Off         | Off or On<br>See CV61 Section                |  |
|  | Split Field Motor  | Off         | Off or On<br>See CV61 Section                | For AC Motors  |
| <b>Scaleable Speed Stabilization (Back EMF)</b>                |  |             |  |  |
| 55   | Static Compensation  | 128         | 00 to 255                                    |  |
| 56   | Dynamic Compensation                                       | 048         | 00 to 255                                    |  |
| 57   | Speed Stabilizer-Droop                                     | 006         | 00 to 15                                     |  |
| <b>SuperSonic (Quiet Operation)</b>                            |  |             |  |  |
| 09   | Motor Frequency SuperSonic                                 | 00          | 00 to 255                                    | Default is MAX   |
| <b>Advanced Consisting</b>                                     |  |             |  |  |
| 19   | Advanced Consist Address                                   | 00          | 00 to 255                                    | Default is OFF   |
| 21   | Advanced Consist Function Control Override for F1-F8       | 00          | See CV21-22 Section                          |  |
| 22   | Advanced Consist Function Control Override for F0 & F9-F12 | 00          | See CV21-22 Section                          |  |
| <b>Function Mapping</b>  |  |             |  |  |
| 33-46  | Function Mapping CVs                                       | 00          | See Function Mapping Section                 |  |
| <b>Decoder Reset to Default Values</b>                         |  |             |  |  |
| 08   | Reset Decoder to Factory Default CV Values                 | 129         | Set to 08 to reset all CV Values.            | Set to 09 to reset all CV Values except 28 step speed table. |
| <b>Decoder IDs</b>   |  |             |  |  |
| 105  | User Private ID #1   | 00          |  | User Defined   |
| 106  | User Private ID #2   | 00          |  | User Defined   |
| 07   | Version ID   | 64          | Digitrax Version ID                          | Read Only  |
| 08   | Manufacturer ID  | 129         | Digitrax                                     | Not affected by reset  |

Information provided here is correct to the best of our knowledge.