DN166I1B 1.5 Amp Decoder for Intermountain N scale FT B units with motor contact "shoes"



Physical	0.472" x 2.165" x 0.98"	Current Rating	1.25/2.0 Amps
Size	11.98mm x 54.99mm x		
	2.4mm		

Interface	Decoder End	Wires		Locomotive End/Plug	
Board Repl	Board Replacement			Board Replacement	

PowerXtender Interface	Decoder End
None	None

# Functions	6	Function	500mA	Function	FX ³
		Current Rating		Туре	
Prod Date	04/28/2014	Discontinued	Current	Replaced By	Current
MSRP	US\$35.00	Feature Set	Series 6	SKU	

FX³ decoders have motor isolation protection. If the decoder senses that the motor is not isolated, it will not run the motor. In this case, you will be able to control the loco's functions but the motor will not work.

CVs are used for this decoder

CV#	Feature	Default	Range	Notes
Locor	notive Address CVs			
01	2 Digit Decoder Address	03	001-127	
17	4 Digit Address (High Byte)	00	0128-9983	CV17 & 18 are used
18	4 Digit Address (Low Byte)	00	0128-9983	Together to program the
				4 digit address. Current
				production Digitrax
				throttles handle this
				automatically. See
				calculator below if
				separate values are
				needed by your system
				for programming 4 digit
				address
29	Configuration Register	06	See CV29	Must be set to a value
	Controls Multiple Features		Value Table	that allows either 2 digit
			Below	or 4 digit addressing
	guration Register CV	I	Γ	
29	Configuration Register	06		
	Address Selection, 2 or 4 digit	2 Digit	2 or 4 Digit	
	Normal Direction of Travel	Fwd	Fwd/Rev	
	(NDOT)			
	Speed Step Control	28/128	14 or 28/128	
	Speed Table On/Off	Off	Speed Table	
			On or Off	
	Analog Mode Conversion On/Off	On	On or Off	
Locor	notion CVs-Control			
Locon	notive Motion			
Chara	acteristics			
Accel	eration and Deceleration			
03	Acceleration Rate	00	00 to 31	128 Steps
04	Deceleration Rate	00	00 to 31	128 Steps
Three	e Step Simple Speed Table & St	art Voltag	ge	
02	Start Voltage	00	00 to 255	128 Steps
05	Maximum Voltage	00	00 to 255	128 Steps
				00, 01 & 255= max
				voltage at step 28
06	Mid Point Voltage	00	00 to 255	128 Steps
				00 & 01= straight line
				curve
	p Speed Tables with 256 Step 1			
65	Kick Start value	00		128 Step Interpolated
66	Forward Trim	00		128 Step Interpolated

67	First Speed Table Entry	00		128 Step Interpolated
68-	28 Step Speed Table Entries	00		128 Step Interpolated
93				1 1
94	Maximum Speed Table Step	00		128 Step Interpolated
95	Reverse Trim	00		128 Step Interpolated
29	Configuration Register	06 Speed Tables are disable d	See Above CV29	Must be set to a value that enables speed tables
Torq	e Compensation and	ŭ		
_	hing Speed			
53 FX ³	FX ³ Decoders do not use CV53	NA	NA	Not Available
53	FX Decoders used CV53 to			See instruction sheet for
FX	designate FX effect generated on F3-Brown Wire			the FX decoder you are using
54 FX ³	FX ³ Decoders use CV54 to control Switching Speed & Torque Compensation	00	00=SS Off, TC On 01=SS On, TC On 16=SS Off, TC Off 17=SS On, TC Off	
53	FX Decoders used CV54 to			See instruction sheet for
FX	designate FX effect generated on F4-White/Yellow Wire			the FX decoder you are using
Funct				
13	DC Functions ON Not Used in FX ³		Automatic	Not Used FX ³
FX ³ F	Sunctions			
49	F0F, forward light effect white	00	See FX ³ section	
50	F0R, reverse light effect yellow	00	See FX ³ section	
51	F1, Function 1 green	00	See FX ³ section	
52	F2, Function 2 violet	00	See FX ³ section	
113	F3, Function 3 brown	00		Not Available
114	F4, function 4 white/yellow	00		Not Available
115	F5, Function F5 white/green	00		Not Available
116	F6, Function F6 white/blue	00		Not Available
62	FX Rate and Keep alive adjust	00	00 to 255	
63	Ditch Light Blink hold time	00	00 to 255	
	Master Light Switch			See FX ³ section

Direc	tional Headlights, Transpondin	ng, Split F	ield Motor	
61	Directional Headlight	Directi	Map F0	Not controlled by CV61
		onal	Forward &	in FX ³ Decoders
			Reverse	
			See CV61	
			Section	
	Transponding	Off	Off or On	
			See CV61	
			Section	
	Split Field Motor	Off	Off or On	For AC Motors
			See CV61	
			Section	
	able Speed Stabilization (Back	EMF)		
55	Static Compensation	128	00 to 255	
56	Dynamic Compensation	048	00 to 255	
57	Speed Stabilizer-Droop	006	00 to 15	
Supe	rSonic (Quiet Operation)			
09	Motor Frequency SuperSonic	00	00 to 255	Default is MAX
Adva	nced Consisting			
19	Advanced Consist Address	00	00 to 255	Default is OFF
21	Advanced Consist Function	00	See CV21-22	
	Control Override for F1-F8		Section	
22	Advanced Consist Function	00	See CV21-22	
	Control Override for F0 &		Section	
	F9-F12			
Func	tion Mapping			
33-	Function Mapping CVs	00	See Function	
46			Mapping	
			Section	
Deco	der Reset to Default Values			
08	Reset Decoder to Factory	129	Set to 08 to	Set to 09 to reset all CV
	Default CV Values		reset all CV	Values except 28 step
			Values.	speed table.
	der IDs	1		
105	User Private ID #1	00		User Defined
106	User Private ID #2	00		User Defined
07	Version ID	64	Digitrax	Read Only
			Version ID	
08	Manufacturer ID	129	Digitrax	Not affected by reset

Information provided here is correct to the best of our knowledge.