DN163K1C 1 Amp N Scale Mobile Decoder for Kato N Scale SD40-2 locos made from year 2006 onward



UPC: 652667-05040-1

Physical .426" x 3.11" w/ LEDs x .195" Size 10.82mm x 78.994mm x 4.953mm	Current Rating	1.0/1.25 Amps
--	----------------	---------------

Interface	Decoder End	Wires		Locomotive End/Plug
Board Repl	Board Replacement			Board Replacement

# Functions	6	Function	500mA	Function	FX^3
		Current Rating		Туре	
Prod Date	2006	Discontinued	Current	Replaced By	Current
MSRP	US\$36.00	Feature Set	Series 3		

FX³ decoders have motor isolation protection. If the decoder senses that the motor is not isolated, it will not run the motor. In this case, you will be able to control the loco's functions but the motor will not work.

CVs are used for this decoder

CV#	Feature	Default	Range	Notes
Locon	notive Address CVs			
01	2 Digit Decoder Address	03	001-127	
17	4 Digit Address (High Byte)	00	0128-9983	CV17 & 18 are used
18	4 Digit Address (Low Byte)	00	0128-9983	Together to program the 4 digit address. Current production Digitrax throttles handle this automatically. See calculator below if separate values are needed by your system for programming 4 digit address
29	Configuration Register	06	See CV29	Must be set to a value
	Controls Multiple Features		Value Table	that allows either 2 digit
			Below	or 4 digit addressing
Confi	guration Register CV			

29	Configuration Register	06		
2)	Address Selection, 2 or 4 digit	2 Digit	2 or 4 Digit	
	Normal Direction of Travel (NDOT)	Fwd	Fwd/Rev	
	Speed Step Control	28/128	14 or 28/128	
	Speed Step Control Speed Table On/Off	Off	Speed Table On or Off	
	Analog Mode Conversion On/Off	On	On or Off	
Loco	motion CVs-Control			
	motion C vs-Control			
	acteristics			
	eration and Deceleration			
03	Acceleration Rate	00	00 to 31	128 Steps
04	Deceleration Rate	00	00 to 31	128 Steps
Three	e Step Simple Speed Table & St	art Volta	ge	-
02	Start Voltage	00	00 to 255	128 Steps
05	Maximum Voltage	00	00 to 255	128 Steps 00, 01 & 255= max voltage at step 28
06	Mid Point Voltage	00	00 to 255	128 Steps 00 & 01= straight line curve
28 Ste	ep Speed Tables with 256 Step 1	Resolution	1	
65	Kick Start value	00		128 Step Interpolated
66	Forward Trim	00		128 Step Interpolated
67	First Speed Table Entry	00		128 Step Interpolated
68- 93	28 Step Speed Table Entries	00		128 Step Interpolated
94	Maximum Speed Table Step	00		128 Step Interpolated
95	Reverse Trim	00		128 Step Interpolated
29	Configuration Register	06 Speed Tables are disable d	See Above CV29	Must be set to a value that enables speed tables
	ue Compensation and hing Speed			
53 FX ³	FX ³ Decoders do not use CV53	NA	NA	Not Available
53 FX	FX Decoders used CV53 to designate FX effect generated on F3-Brown Wire			See instruction sheet for the FX decoder you are using
54 FX ³	FX ³ Decoders use CV54 to control Switching Speed & Torque Compensation	00	00=SS Off, TC On 01=SS On, TC On 16=SS Off, TC	

			Off	
			17=SS On, TC	
			Off	
53	FX Decoders used CV54 to			See instruction sheet for
FX	designate FX effect generated			the FX decoder you are
111	on F4-White/Yellow Wire			using
Funct				
13	DC Functions ON Not Used		Automatic	Not Used FX ³
15	in FX ³		1 Intollinutio	
FX ³ F	Sunctions			
49	F0F, forward light effect	00	See FX ³	
12	white	00	section	
50	FOR, reverse light effect	00	See FX ³	
50	yellow	00	section	
51	F1, Function 1 green	00	See FX ³	
51			section	
52	F2, Function 2 violet	00	See FX ³	
52			section	
113	F3, Function 3 brown	00	section	Not Available
113	F4, function 4 white/yellow	00		Not Available
114		00		Not Available
115	F5, Function F5 white/green	00		Not Available
	F6, Function F6 white/blue		00 4- 255	Not Available
62	FX Rate and Keep alive	00	00 to 255	
(2)	adjust	00	00 / 055	
63	Ditch Light Blink hold time	00	00 to 255	
D	Master Light Switch			See FX ³ section
	tional Headlights, Transpondir			
61	Directional Headlight	Directi	Map F0	Not controlled by CV61 in FX ³ Decoders
		onal	Forward &	in FX ⁻ Decoders
			Reverse	
			See CV61	
		0.00	Section	
	Transponding	Off	Off or On	
			See CV61	
			Section	
	Split Field Motor	Off	Off or On	For AC Motors
			See CV61	
a -			Section	
	able Speed Stabilization (Back		00 / 055	
55	Static Compensation	128	00 to 255	
56	Dynamic Compensation	048	00 to 255	
57	Speed Stabilizer-Droop	006	00 to 15	
-	Sonic (Quiet Operation)			
09	Motor Frequency SuperSonic	00	00 to 255	Default is MAX
	nced Consisting	I		
19	Advanced Consist Address	00	00 to 255	Default is OFF
21	Advanced Consist Function	00	See CV21-22	
		1	1 ~ ·	1
	Control Override for F1-F8		Section	

	Control Override for F0 & F9-F12		Section	
Funct	tion Mapping			
33-	Function Mapping CVs	00	See Function	
46	i uneuon mapping e vis	00	Mapping	
10			Section	
Decod	ler Reset to Default Values			
08	Reset Decoder to Factory	129	Set to 08 to	Set to 09 to reset all CV
	Default CV Values		reset all CV	Values except 28 step
			Values.	speed table.
Decod	ler IDs			
105	User Private ID #1	00		User Defined
106	User Private ID #2	00		User Defined
07	Version ID	64	Digitrax	Read Only
			Version ID	-
08	Manufacturer ID	129	Digitrax	Not affected by reset

Information provided here is correct to the best of our knowledge.