## **Digitrax Throttle Specification Sheet**

## **DT400R Super Radio Throttle**



Compatibility	All LocoNet Systems	
Function Control	(0-12 with DCS100/DCS50) (0-8 with	
	DB150)	
Wireless Operation	With Simplex Receiver (UR91)	
Turnout, Stationary Decoder Control	Yes	
Turnout Addresses	999	
Locomotive Decoder Addresses	9,000	
Decoder Programming	Yes, Tethered	
Screen	Multi Line LCD	
Throttle Control	Dual Encoders	
2 & 4 Digit Addressing	Yes	
Recall Feature	Yes	
Transponding Find Feature	Yes	
Flashlight	Yes	
Fast Clock	Yes	
Cab Signaling	Yes	

<b>Prod Date</b>	10/07/2006	Discontinued	2009	Replaced By	DT402R
MSRP	US\$229.99			SKU	

Mode Indicator				
Display	Mode	Used For		
Fn	Function	Normal locomotive operation functions available on the keypad		
Lo	Loco Selection	Locomotive Address Selection Mode		
Mu	MU	Multiple unit (consist) operation set up and break up		
Sw	Switch	Accessory decoder control (turnouts, etc.) or option switch control		
Pw	Power	Turn track power on and off		
SE	Status Edit	Change locomotive speed steps to 14, 28, or 128 as needed		
PG	Programming	Paged-Digitrax preferred method		
PH	Programming	Physical Register		
Pd	Programming	Direct		
Po	Programming	Operations Mode (Ops Mode) programming on the mainline		
RE	Recall	Recall one of the last 4, 8, or 16 locomotive addresses used		
Fd	Find	Find command issued for active loco, results displayed in text area		
Ec	Edit clock	Edit the time shown on the fast clock		
EF	Edit clock rate	Edit fast clock rate		
EA	Edit alarm	Edit the alarm time set for the throttle		
Er	Edit routes	Edit routes-shows when your system is running with a DCS100 with routes enabled		
E1	Change LocoNet ID	Change LocoNet ID for Infrared or Radio Operation		
E?	Other edit modes	Show when your system is running with a LocoNet component that is enabled for additional functionality such as signaling.		

Digitrax, Inc. is not responsible for unintentional errors or omissions in this document.